

## VAZ Ver.: 13.02

Vehicle	System	Sys. Info.	Read-Clear code	Data Stream	Actuation	Special Functions	Others
BOSCH	BOSCH M1.5.4	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	BOSCH M1.5.4+	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	BOSCH M1.5.4N	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	BOSCH MP7.0 E2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	BOSCH MP7.0 E3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	BOSCH MP7.9.7 E2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.ACP Circuit 2.Brake 3.Additional check	1.Faulty in reading datastream 2.Operating organization
	BOSCH MP7.9.7 E3	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.ACP Circuit 2.Brake 3.Additional check	1.Faulty in reading datastream 2.Operating organization
GM	GM ISFI-2S	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Device code	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	GM EFI4,ITMS6F	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Device code	1.Faulty in reading datastream 2.Check damaged parts
Jan.	Jan. 5.1.X	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts

	Jan. 5.1.	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
	Jan. 7.2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts
VS 5.1	VS 5.1 E2	<i>info</i>	<i>err.code</i>	<i>data</i>	<i>actuat.</i>	1.Additional check 2.ACP Circuit	1.Faulty in reading datastream 2.Faulty in reading stored data 3.Check damaged parts